BAKERSFIELD COLLEGE

Media Services

395-4516

Multimedia Cart- Quick Start Instructions

Getting Started

Equipment includes:

——— Speaker Amplifier

——— VGA cable for Laptop

——— Switch Box

——— DVD/VHS Player

1.

Turn the projector on by pressing the green Projector Power button on the switch box.

Playing a DVD or Videocassette

Press the **Power** button to turn on the DVD player.

Press **DVD/VCR** input button on the switch box.

Load the DVD or VHS into the player and press play.

Note: If you do not see an image, make sure the appropriate button on the DVD/VHS player is selected.

Using a Laptop

1. Connect the **VGA** cable to your laptop monitor output.

2. Turn your laptop on.



3.

Press the **LAPTOP** input button on the switch box.

See back for using Sound ⟶

Using Sound

1.

The amplifier to control the speakers is located on the top shelf of the cart.

2.

Turn on the power for the speakers.
On = Red light **Off** = No light.

3.

To adjust the volume,
use the knobs on the left and right.

Important! ***Please turn all equipment off at the end of class!***

Call us now to schedule individual or department training! 395-4516